

## Template No. 5 250659 5

Precise routings for a certain hinge can be conducted by means of the proper templates

<b>Lehrentechnik</b>	single
----------------------	--------

### Installation aids

TE 630 3D
-----------

TE 640 3D
-----------

TE 640 3D A8
--------------

**Items** (DIN direction: without)

<b>finish(es)</b>	without
<b>Packing unit</b>	Pack of 1
<b>Item number</b>	5 250659 5 00001



## Template No. 5 250689 5

Precise routings for a certain hinge can be conducted by means of the proper templates

Lehrentechnik

single

### Installation aids

TE 640 3D

TE 640 3D A8

