Behringer WING EDIT Firmware

Version 3.2.1 (28 Apr 2025)

WING EDIT 3.2 introduces key features that were previously available only on the console, including CUSTOM CONTROLS and GLOBAL SAFES, along with workflow enhancements from WING firmware 3.0.6.

Additionally, WING EDIT 3.2 offers exclusive new features, such as dedicated pop-up windows for plug-ins in the FX RACK and CUSTOM CONTROLS.

NOTE: WING firmware 3.0.6 is required to run WING EDIT 3.2.

Added:

- Editing screens for all CUSTOM CONTROLS

- 4 pop-up windows for CUSTOM CONTROLS

- 16 pop-up windows for effects accessible through the EFFECTS screen and the INSERT slots

- Keyboard shortcuts assignments on SETUP > GENERAL

- All fader types can now be assigned to WING Edit layers (BUS sends, BUS to BUS sends, FX parameters, MIDI CC)

- WING Edit layers added to LIBRARY SCOPE and stored in SNAPSHOTS

- GLOBAL SAFES accessible on the LIBRARY screen

- WING model displayed on the top left corner

- Next/previous channel, INIT and COPY toolbox available on the FILTER screen

- COPY function for all compatible parameters between different channel types

- Warning when REC FOCUS function for snippets has no parameters selected

- Warning when an M/S source is assigned to an AUX channel

- Adjustable LC and HC filter slopes

- New BUS FEED CONFIGURATION window as introduced on fw3.0.5

- Option to change the main fader assignment to any MAIN, MTX, or DCA

- Option to disable the DISCONNECT WARNING dialog (SETUP > GENERAL)

- AES50 error counter on the SETUP > AUDIO screen to help identify faulty cables and connections (COR = corrected; UNC = uncorrected)

- Hold down the HA REMOTE / RCV CUST button to apply settings to all sources in the selected group

- Reset EQ band by holding down the band selection button

Changed:

- Removed send from a BUS to the same BUS (from the SENDS screen)
- Channel color removed if scribble strip LIGHT is turned off
- Default BUS mode removed (replaced by BUS FEED CONFIGURATION)
- SEND mode link removed and improved SEND options pop-up
- COPY tool: source channel indicated with white outline
- Changed colors of the EQ filter selection and INIT buttons
- SD recorder system error messages shown as text
- Fader layer button text changed from "CH 33-40" to "CH 33-A8" (needs fader layer INIT)
- Refined ULTRATAP DELAY's SPREAD algorithm

Fixed:

- V3.2.1: Fixed crash when selecting a MAIN or MTX channel and adjusting a CC encoder set to SEL BUS SEND
- Selected LIBRARY file name updated after renaming
- ADD function on open SHOW
- SNIPPET SCOPE issues and missing entries with REC or ADD functions
- Channel preset load FX warning even when insert points are not part of the SCOPE
- Wrong "SOURCE IN USE" display issue (ST CONNECT)
- BUS SENDS and BUS to BUS fader assignment bug
- MASTERING LIMITER on/off status
- BUS fader assignment bug on USER 2 layer (WING COMPACT)
- RTA issues on GEQ and COMBINATOR
- Mixer synchronization with the "PC to MIXER" function
- Wrong MAIN to MAIN SOF-frame
- Crash when exiting MUTE GROUPS configuration pop-up (on macOS)
- Connection issues with multiple app instances (on Windows)
- Various small fixes