




Programming connections

Supported Programmers:							
● Noahlink Wireless 2 / Noahlink Wireless / Wireless ● HiPro 2 / HiPro USB / SpeedPort 2 / SpeedPort / Noahlink							
Product	 RIC 312	 RIC RT/RIC R	 mRIC R	 P BTE 13 & UP BTE 13	 2.4 GHz Custom	 Custom NW	 CIC R NW
Omega AI+	●	● (RIC RT)	●	N/A	●	●	●
Edge AI	●	● (RIC RT)	●	N/A	●	N/A	N/A
G Series AI	●	● (RIC R)	N/A	●	●	●	N/A

Cable connections

Omega AI+
G Series AI (CIC NW only)



NOTES

- It is recommended that a battery be in the hearing aid when programming with a flex strip.
- VC position does not matter as the hearing aid volume control is disabled during programming.
- Starkey uses purple programming cables. Flex strips will connect to the cables.
- Programming cables and flex strips can be ordered on StarkeyPro.com
- Status Indicator Light (LED) shown on RIC RT & mRIC R product images applies to Omega AI+ only.
- Color options vary between product families.
- Programming for Omega AI wireless & Signature Series non-wireless products follow Omega AI+ products.