

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Omega AI RIC RT			
Omega AI 24 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8154	3*
Omega AI 24 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8155	3*
Omega AI 24 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8156	3*
Omega AI 24 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9720	3*
Omega AI 20 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8147	3*
Omega AI 20 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8148	3*
Omega AI 20 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8149	3*
Omega AI 20 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9719	3*
Omega AI 16 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8140	3*
Omega AI 16 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8141	3*
Omega AI 16 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.8142	3*
Omega AI 16 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9718	3*
Omega AI RIC RT (Tinnitus)			
Omega AI 24 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5924	3*
Omega AI 24 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5925	3*
Omega AI 24 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5926	3*
Omega AI 20 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5918	3*
Omega AI 20 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5919	3*
Omega AI 20 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5920	3*
Omega AI 16 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5915	3*
Omega AI 16 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5916	3*
Omega AI 16 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5917	3*
Omega AI RIC 312			
Omega AI 24 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4414	3*
Omega AI 24 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4415	3*
Omega AI 24 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4416	3*
Omega AI 24 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4417	3*
Omega AI 20 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4410	3*
Omega AI 20 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4411	3*
Omega AI 20 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4412	3*
Omega AI 20 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4413	3*
Omega AI 16 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4406	3*
Omega AI 16 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4407	3*
Omega AI 16 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4408	3*
Omega AI 16 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4409	3*
Omega AI RIC 312 (Tinnitus)			
Omega AI 24 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5812	3*
Omega AI 24 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5813	3*
Omega AI 24 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5814	3*
Omega AI 20 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5809	3*
Omega AI 20 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5810	3*
Omega AI 20 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5811	3*
Omega AI 16 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5806	3*
Omega AI 16 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5807	3*
Omega AI 16 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5808	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Omega AI mRIC R			
Omega AI 24 mRIC R L	mRIC R Sensorik Taster	13.20.25.8150	3*
Omega AI 24 mRIC R M	mRIC R Sensorik Taster	13.20.25.8151	3*
Omega AI 24 mRIC R P	mRIC R Sensorik Taster	13.20.25.8152	3*
Omega AI 24 mRIC R UP	mRIC R Sensorik Taster	13.20.25.8153	3*
Omega AI 20 mRIC R L	mRIC R Sensorik Taster	13.20.25.8143	3*
Omega AI 20 mRIC R M	mRIC R Sensorik Taster	13.20.25.8144	3*
Omega AI 20 mRIC R P	mRIC R Sensorik Taster	13.20.25.8145	3*
Omega AI 20 mRIC R UP	mRIC R Sensorik Taster	13.20.25.8146	3*
Omega AI 16 mRIC R L	mRIC R Sensorik Taster	13.20.25.8136	3*
Omega AI 16 mRIC R M	mRIC R Sensorik Taster	13.20.25.8137	3*
Omega AI 16 mRIC R P	mRIC R Sensorik Taster	13.20.25.8138	3*
Omega AI 16 mRIC R UP	mRIC R Sensorik Taster	13.20.25.8139	3*
Omega AI mRIC R (Tinnitus)			
Omega AI 24 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5921	3*
Omega AI 24 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5922	3*
Omega AI 24 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5923	3*
Omega AI 20 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5912	3*
Omega AI 20 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5913	3*
Omega AI 20 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5914	3*
Omega AI 16 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5909	3*
Omega AI 16 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5910	3*
Omega AI 16 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5911	3*
Omega AI ITE R			
Omega AI 24 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8761	3*
Omega AI 24 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8762	3*
Omega AI 24 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8763	3*
Omega AI 24 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8764	3*
Omega AI 24 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8765	3*
Omega AI 24 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8766	3*
Omega AI 20 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8755	3*
Omega AI 20 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8756	3*
Omega AI 20 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8757	3*
Omega AI 20 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8758	3*
Omega AI 20 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8759	3*
Omega AI 20 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8760	3*
Omega AI 16 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8749	3*
Omega AI 16 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8750	3*
Omega AI 16 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8751	3*
Omega AI 16 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8752	3*
Omega AI 16 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8753	3*
Omega AI 16 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8754	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Omega AI ITC R			
Omega AI 24 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8851	3*
Omega AI 24 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8852	3*
Omega AI 24 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8853	3*
Omega AI 24 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8854	3*
Omega AI 24 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8855	3*
Omega AI 24 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8856	3*
Omega AI 24 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8857	3*
Omega AI 24 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8858	3*
Omega AI 20 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8867	3*
Omega AI 20 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8868	3*
Omega AI 20 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8869	3*
Omega AI 20 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8870	3*
Omega AI 20 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8871	3*
Omega AI 20 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8872	3*
Omega AI 20 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8873	3*
Omega AI 20 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8874	3*
Omega AI 16 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8843	3*
Omega AI 16 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8844	3*
Omega AI 16 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8845	3*
Omega AI 16 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8846	3*
Omega AI 16 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8847	3*
Omega AI 16 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8848	3*
Omega AI 16 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8849	3*
Omega AI 16 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8850	3*
Omega AI CIC 312 Wireless			
Omega AI 24 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.25.5140	3*
Omega AI 24 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.25.5141	3*
Omega AI 24 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.25.5142	3*
Omega AI 24 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.25.5143	3*
Omega AI 20 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.25.5136	3*
Omega AI 20 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.25.5137	3*
Omega AI 20 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.25.5138	3*
Omega AI 20 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.25.5139	3*
Omega AI 16 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.25.5132	3*
Omega AI 16 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.25.5133	3*
Omega AI 16 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.25.5134	3*
Omega AI 16 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.25.5135	3*
G Series AI			
G Series AI 16 RIC 312 L	RIC 312 (wireless)	13.20.22.4464	2*
G Series AI 16 RIC 312 M	RIC 312 (wireless)	13.20.22.4465	2*
G Series AI 16 RIC 312 P	RIC 312 (wireless)	13.20.22.4466	2*
G Series AI 16 RIC 312 UP	RIC 312 (wireless)	13.20.22.4467	2*
G Series AI 12 RIC 312 L	RIC 312 (wireless)	13.20.22.4460	2*
G Series AI 12 RIC 312 M	RIC 312 (wireless)	13.20.22.4461	2*
G Series AI 12 RIC 312 P	RIC 312 (wireless)	13.20.22.4462	2*
G Series AI 12 RIC 312 UP	RIC 312 (wireless)	13.20.22.4463	2*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
G Series AI 10 RIC 312 L	RIC 312 (wireless)	13.20.22.1999	1*
G Series AI 10 RIC 312 M	RIC 312 (wireless)	13.20.22.4457	1*
G Series AI 10 RIC 312 P	RIC 312 (wireless)	13.20.22.4458	1*
G Series AI 10 RIC 312 UP	RIC 312 (wireless)	13.20.22.4459	1*
G Series AI (Tinnitus)			
G Series AI 16 RIC 312 L (Tinnitus)	RIC 312 (wireless)	13.20.14.5874	2*
G Series AI 16 RIC 312 M (Tinnitus)	RIC 312 (wireless)	13.20.14.5875	2*
G Series AI 16 RIC 312 P (Tinnitus)	RIC 312 (wireless)	13.20.14.5876	2*
G Series AI 12 RIC 312 L (Tinnitus)	RIC 312 (wireless)	13.20.14.5871	1*
G Series AI 12 RIC 312 M (Tinnitus)	RIC 312 (wireless)	13.20.14.5872	1*
G Series AI 12 RIC 312 P (Tinnitus)	RIC 312 (wireless)	13.20.14.5873	1*
G Series AI			
G Series AI 16 RIC R L	RIC R (wireless)	13.20.25.8395	2*
G Series AI 16 RIC R M	RIC R (wireless)	13.20.25.8396	2*
G Series AI 16 RIC R P	RIC R (wireless)	13.20.25.8397	2*
G Series AI 16 RIC R UP	RIC R (wireless)	13.20.25.8398	2*
G Series AI 12 RIC R L	RIC R (wireless)	13.20.25.8391	2*
G Series AI 12 RIC R M	RIC R (wireless)	13.20.25.8392	2*
G Series AI 12 RIC R P	RIC R (wireless)	13.20.25.8393	2*
G Series AI 12 RIC R UP	RIC R (wireless)	13.20.25.8394	2*
G Series AI 10 RIC R L	RIC R (wireless)	13.20.25.8387	1*
G Series AI 10 RIC R M	RIC R (wireless)	13.20.25.8388	1*
G Series AI 10 RIC R P	RIC R (wireless)	13.20.25.8389	1*
G Series AI 10 RIC R UP	RIC R (wireless)	13.20.25.8390	1*
G Series AI (Tinnitus)			
G Series AI 16 RIC R L (Tinnitus)	RIC R (wireless)	13.20.14.7116	2*
G Series AI 16 RIC R M (Tinnitus)	RIC R (wireless)	13.20.14.7117	2*
G Series AI 16 RIC R P (Tinnitus)	RIC R (wireless)	13.20.14.7118	2*
G Series AI 12 RIC R L (Tinnitus)	RIC R (wireless)	13.20.14.7113	1*
G Series AI 12 RIC R M (Tinnitus)	RIC R (wireless)	13.20.14.7114	1*
G Series AI 12 RIC R P (Tinnitus)	RIC R (wireless)	13.20.14.7115	1*
G Series AI P BTE 13			
G Series AI 24 P BTE 13	BTE (wireless)	13.20.22.4482	3*
G Series AI 20 P BTE 13	BTE (wireless)	13.20.22.4481	3*
G Series AI 16 P BTE 13	BTE (wireless)	13.20.22.4480	3*
G Series AI 12 P BTE 13	BTE (wireless)	13.20.22.4479	2*
G Series AI 10 P BTE 13	BTE (wireless)	13.20.22.4478	2*
G Series AI P BTE 13			
G Series AI 24 P BTE 13 (Tinnitus)	BTE (wireless)	13.20.14.2272	3*
G Series AI 20 P BTE 13 (Tinnitus)	BTE (wireless)	13.20.14.2269	3*
G Series AI 16 P BTE 13 (Tinnitus)	BTE (wireless)	13.20.14.2266	3*
G Series AI 12 P BTE 13 (Tinnitus)	BTE (wireless)	13.20.14.2263	2*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
G Series AI UP BTE 13			
G Series AI 24 UP BTE 13	BTE (wireless)	13.20.10.1362	3*
G Series AI 20 UP BTE 13	BTE (wireless)	13.20.10.1361	3*
G Series AI 16 UP BTE 13	BTE (wireless)	13.20.10.1360	3*
G Series AI 12 UP BTE 13	BTE (wireless)	13.20.10.1359	2*
G Series AI 10 UP BTE 13	BTE (wireless)	13.20.10.1358	2*
Edge AI			
Edge AI RIC RT			
Edge AI 24 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9617	3*
Edge AI 24 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9618	3*
Edge AI 24 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9619	3*
Edge AI 24 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9594	3*
Edge AI 20 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9624	3*
Edge AI 20 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9625	3*
Edge AI 20 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9626	3*
Edge AI 20 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9593	3*
Edge AI 16 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9631	3*
Edge AI 16 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9632	3*
Edge AI 16 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9633	3*
Edge AI 16 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9592	3*
Edge AI RIC RT (Tinnitus)			
Edge AI 24 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5604	3*
Edge AI 24 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5605	3*
Edge AI 24 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5606	3*
Edge AI 20 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5610	3*
Edge AI 20 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5611	3*
Edge AI 20 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5612	3*
Edge AI 16 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5616	3*
Edge AI 16 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5617	3*
Edge AI 16 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5618	3*
Edge AI RIC 312			
Edge AI 24 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4038	3*
Edge AI 24 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4039	3*
Edge AI 24 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4040	3*
Edge AI 24 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4041	3*
Edge AI 20 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4034	3*
Edge AI 20 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4035	3*
Edge AI 20 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4036	3*
Edge AI 20 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4037	2*
Edge AI 16 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4030	2*
Edge AI 16 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4031	2*
Edge AI 16 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4032	3*
Edge AI 16 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4033	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Edge AI RIC 312 (Tinnitus)			
Edge AI 24 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5516	3*
Edge AI 24 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5517	3*
Edge AI 24 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5518	3*
Edge AI 20 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5513	3*
Edge AI 20 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5514	3*
Edge AI 20 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5515	3*
Edge AI 16 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5510	3*
Edge AI 16 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5511	3*
Edge AI 16 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5512	3*
Edge AI mRIC R			
Edge AI 24 mRIC R L	mRIC R Sensorik Taster	13.20.25.9620	3*
Edge AI 24 mRIC R M	mRIC R Sensorik Taster	13.20.25.9621	3*
Edge AI 24 mRIC R P	mRIC R Sensorik Taster	13.20.25.9622	3*
Edge AI 24 mRIC R UP	mRIC R Sensorik Taster	13.20.25.9623	3*
Edge AI 20 mRIC R L	mRIC R Sensorik Taster	13.20.25.9627	3*
Edge AI 20 mRIC R M	mRIC R Sensorik Taster	13.20.25.9628	3*
Edge AI 20 mRIC R P	mRIC R Sensorik Taster	13.20.25.9629	3*
Edge AI 20 mRIC R UP	mRIC R Sensorik Taster	13.20.25.9630	3*
Edge AI 16 mRIC R L	mRIC R Sensorik Taster	13.20.25.9634	3*
Edge AI 16 mRIC R M	mRIC R Sensorik Taster	13.20.25.9635	3*
Edge AI 16 mRIC R P	mRIC R Sensorik Taster	13.20.25.9636	3*
Edge AI 16 mRIC R UP	mRIC R Sensorik Taster	13.20.25.9637	3*
Edge AI mRIC R (Tinnitus)			
Edge AI 24 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5607	3*
Edge AI 24 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5608	3*
Edge AI 24 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5609	3*
Edge AI 20 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5613	3*
Edge AI 20 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5614	3*
Edge AI 20 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5615	3*
Edge AI 16 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5619	3*
Edge AI 16 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5620	3*
Edge AI 16 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5621	3*
Edge AI ITE R			
Edge AI 24 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8599	3*
Edge AI 24 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8600	3*
Edge AI 24 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8601	3*
Edge AI 24 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8602	3*
Edge AI 24 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8604	3*
Edge AI 24 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8603	3*
Edge AI 20 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8584	3*
Edge AI 20 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8585	3*
Edge AI 20 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8586	3*
Edge AI 20 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8587	3*
Edge AI 20 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8588	3*
Edge AI 20 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8589	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Edge AI 16 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8571	3*
Edge AI 16 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8572	3*
Edge AI 16 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8573	3*
Edge AI 16 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8574	3*
Edge AI 16 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8575	3*
Edge AI 16 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8576	3*

Edge AI ITC R

Edge AI 24 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8591	3*
Edge AI 24 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8592	3*
Edge AI 24 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8593	3*
Edge AI 24 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8594	3*
Edge AI 24 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8595	3*
Edge AI 24 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8596	3*
Edge AI 24 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8597	3*
Edge AI 24 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8598	3*
Edge AI 20 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8577	3*
Edge AI 20 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8578	3*
Edge AI 20 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8590	3*
Edge AI 20 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8579	3*
Edge AI 20 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8580	3*
Edge AI 20 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8581	3*
Edge AI 20 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8582	3*
Edge AI 20 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8583	3*
Edge AI 16 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8563	3*
Edge AI 16 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8564	3*
Edge AI 16 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8565	3*
Edge AI 16 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8566	3*
Edge AI 16 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8567	3*
Edge AI 16 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8568	3*
Edge AI 16 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8569	3*
Edge AI 16 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8570	3*

Edge AI CIC 312 Wireless

Edge AI 24 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.22.7638	3*
Edge AI 24 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.22.7639	3*
Edge AI 24 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.22.7640	3*
Edge AI 24 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.22.7641	3*
Edge AI 20 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.22.7634	3*
Edge AI 20 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.22.7635	3*
Edge AI 20 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.22.7636	3*
Edge AI 20 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.22.7637	3*
Edge AI 16 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.22.7630	3*
Edge AI 16 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.22.7631	3*
Edge AI 16 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.22.7632	3*
Edge AI 16 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.22.7633	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Genesis AI			
Genesis AI RIC RT			
Genesis AI 24 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9998	3*
Genesis AI 24 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9992	3*
Genesis AI 24 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9991	3*
Genesis AI 24 RIC RT UP-	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9994	3*
Genesis AI 24 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9487	3*
Genesis AI 20 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9983	3*
Genesis AI 20 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9985	3*
Genesis AI 20 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9982	3*
Genesis AI 20 RIC RT UP-	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9987	3*
Genesis AI 20 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9486	3*
Genesis AI 16 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9973	3*
Genesis AI 16 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9976	3*
Genesis AI 16 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9979	3*
Genesis AI 16 RIC RT UP-	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.23.9981	3*
Genesis AI 16 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9488	3*
Genesis AI 12 RIC RT L	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9698	2*
Genesis AI 12 RIC RT M	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9699	2*
Genesis AI 12 RIC RT P	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9700	2*
Genesis AI 12 RIC RT UP-	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.25.9701	2*
Genesis AI 12 RIC RT UP	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.10.9606	2*
Genesis AI RIC RT (Tinnitus)			
Genesis AI 24 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5273	3*
Genesis AI 24 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5271	3*
Genesis AI 24 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5272	3*
Genesis AI 20 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5264	3*
Genesis AI 20 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5266	3*
Genesis AI 20 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5263	3*
Genesis AI 16 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5261	3*
Genesis AI 16 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5257	3*
Genesis AI 16 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5256	3*
Genesis AI 12 RIC RT L (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5657	2*
Genesis AI 12 RIC RT M (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5658	2*
Genesis AI 12 RIC RT P (Tinnitus)	RIC RT (Li-Ion Akku) Sensorik NFMI Wippschalter	13.20.24.5659	2*
Genesis AI RIC 312			
Genesis AI 24 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3831	3*
Genesis AI 24 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3842	3*
Genesis AI 24 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3836	3*
Genesis AI 24 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3834	3*
Genesis AI 20 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3839	3*
Genesis AI 20 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3840	3*
Genesis AI 20 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3838	3*
Genesis AI 20 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3835	3*
Genesis AI 16 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3837	3*
Genesis AI 16 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3841	3*
Genesis AI 16 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3832	3*
Genesis AI 16 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.3833	3*
Genesis AI 12 RIC 312 L	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4074	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Genesis AI 12 RIC 312 M	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4075	3*
Genesis AI 12 RIC 312 P	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4076	3*
Genesis AI 12 RIC 312 UP	RIC 312 Sensorik NFMI Wippschalter	13.20.22.4077	3*
Genesis AI RIC 312 (Tinnitus)			
Genesis AI 24 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5339	3*
Genesis AI 24 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5341	3*
Genesis AI 24 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5335	3*
Genesis AI 20 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5336	3*
Genesis AI 20 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5340	3*
Genesis AI 20 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5337	3*
Genesis AI 16 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5342	3*
Genesis AI 16 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5334	3*
Genesis AI 16 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5338	3*
Genesis AI 12 RIC 312 L (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5543	2*
Genesis AI 12 RIC 312 M (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5544	2*
Genesis AI 12 RIC 312 P (Tinnitus)	RIC 312 Sensorik NFMI Wippschalter	13.20.14.5545	2*
Genesis AI mRIC R			
Genesis AI 24 mRIC R L	mRIC R Sensorik Taster	13.20.23.9999	3*
Genesis AI 24 mRIC R M	mRIC R Sensorik Taster	13.20.23.9997	3*
Genesis AI 24 mRIC R P	mRIC R Sensorik Taster	13.20.23.9995	3*
Genesis AI 24 mRIC R UP-	mRIC R Sensorik Taster	13.20.23.9993	3*
Genesis AI 24 mRIC R UP	mRIC R Sensorik Taster	13.20.23.9996	3*
Genesis AI 20 mRIC R L	mRIC R Sensorik Taster	13.20.23.9984	3*
Genesis AI 20 mRIC R M	mRIC R Sensorik Taster	13.20.23.9989	3*
Genesis AI 20 mRIC R P	mRIC R Sensorik Taster	13.20.23.9986	3*
Genesis AI 20 mRIC R UP-	mRIC R Sensorik Taster	13.20.23.9988	3*
Genesis AI 20 mRIC R UP	mRIC R Sensorik Taster	13.20.23.9990	3*
Genesis AI 16 mRIC R L	mRIC R Sensorik Taster	13.20.23.9980	3*
Genesis AI 16 mRIC R M	mRIC R Sensorik Taster	13.20.23.9974	3*
Genesis AI 16 mRIC R P	mRIC R Sensorik Taster	13.20.23.9977	3*
Genesis AI 16 mRIC R UP-	mRIC R Sensorik Taster	13.20.23.9978	3*
Genesis AI 16 mRIC R UP	mRIC R Sensorik Taster	13.20.23.9975	3*
Genesis AI 12 mRIC R L	mRIC R Sensorik Taster	13.20.25.9693	2*
Genesis AI 12 mRIC R M	mRIC R Sensorik Taster	13.20.25.9694	2*
Genesis AI 12 mRIC R P	mRIC R Sensorik Taster	13.20.25.9695	2*
Genesis AI 12 mRIC R UP-	mRIC R Sensorik Taster	13.20.25.9696	2*
Genesis AI 12 mRIC R UP	mRIC R Sensorik Taster	13.20.25.9697	2*
Genesis AI mRIC R (Tinnitus)			
Genesis AI 24 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5269	3*
Genesis AI 24 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5268	3*
Genesis AI 24 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5270	3*
Genesis AI 20 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5262	3*
Genesis AI 20 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5267	3*
Genesis AI 20 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5265	3*
Genesis AI 16 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5259	3*
Genesis AI 16 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5260	3*
Genesis AI 16 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5258	3*
Genesis AI 12 mRIC R L (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5654	2*
Genesis AI 12 mRIC R M (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5655	2*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Genesis AI 12 mRIC R P (Tinnitus)	mRIC R Sensorik Taster	13.20.24.5656	2*
Genesis AI ITE R			
Genesis AI 24 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8224	3*
Genesis AI 24 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8223	3*
Genesis AI 24 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8226	3*
Genesis AI 24 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8222	3*
Genesis AI 24 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8225	3*
Genesis AI 24 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8221	3*
Genesis AI 20 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8207	3*
Genesis AI 20 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8208	3*
Genesis AI 20 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8211	3*
Genesis AI 20 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8209	3*
Genesis AI 20 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8212	3*
Genesis AI 20 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8210	3*
Genesis AI 16 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.22.8928	3*
Genesis AI 16 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.22.8966	3*
Genesis AI 16 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8198	3*
Genesis AI 16 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.22.8961	3*
Genesis AI 16 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.22.8962	3*
Genesis AI 16 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.22.8899	3*
Genesis AI 12 ITE R DIR M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8641	2*
Genesis AI 12 ITE R DIR P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8642	2*
Genesis AI 12 ITE R DIR UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8643	2*
Genesis AI 12 ITE R Omni M	ITE R (Li-Ion Akku) Sensorik	13.20.23.8644	2*
Genesis AI 12 ITE R Omni P	ITE R (Li-Ion Akku) Sensorik	13.20.23.8645	2*
Genesis AI 12 ITE R Omni UP	ITE R (Li-Ion Akku) Sensorik	13.20.23.8646	2*
Genesis AI ITC R			
Genesis AI 24 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8217	3*
Genesis AI 24 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8220	3*
Genesis AI 24 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8214	3*
Genesis AI 24 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8215	3*
Genesis AI 24 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8216	3*
Genesis AI 24 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8219	3*
Genesis AI 24 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8213	3*
Genesis AI 24 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8218	3*
Genesis AI 20 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8204	3*
Genesis AI 20 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8203	3*
Genesis AI 20 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8202	3*
Genesis AI 20 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8199	3*
Genesis AI 20 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8206	3*
Genesis AI 20 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8200	3*
Genesis AI 20 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8201	3*
Genesis AI 20 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8205	3*
Genesis AI 16 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.22.8837	3*
Genesis AI 16 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.22.8799	3*
Genesis AI 16 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.22.8869	3*
Genesis AI 16 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.22.8805	3*
Genesis AI 16 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.22.8868	3*
Genesis AI 16 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.22.8778	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Genesis AI 16 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.22.8898	3*
Genesis AI 16 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.22.8759	3*
Genesis AI 12 ITC R DIR L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8633	2*
Genesis AI 12 ITC R DIR M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8634	2*
Genesis AI 12 ITC R DIR P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8635	2*
Genesis AI 12 ITC R DIR UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8636	2*
Genesis AI 12 ITC R Omni L	ITC R (Li-Ion Akku) Sensorik	13.20.23.8637	2*
Genesis AI 12 ITC R Omni M	ITC R (Li-Ion Akku) Sensorik	13.20.23.8638	2*
Genesis AI 12 ITC R Omni P	ITC R (Li-Ion Akku) Sensorik	13.20.23.8639	2*
Genesis AI 12 ITC R Omni UP	ITC R (Li-Ion Akku) Sensorik	13.20.23.8640	2*

Genesis AI CIC 312 Wireless

Genesis AI 24 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.22.7372	3*
Genesis AI 24 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.22.7379	3*
Genesis AI 24 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.22.7377	3*
Genesis AI 24 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.22.7373	3*
Genesis AI 20 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.22.7381	3*
Genesis AI 20 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.22.7376	3*
Genesis AI 20 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.22.7371	3*
Genesis AI 20 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.22.7380	3*
Genesis AI 16 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.22.7374	3*
Genesis AI 16 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.22.7378	3*
Genesis AI 16 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.22.7375	3*
Genesis AI 16 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.22.7370	2*
Genesis AI 12 CIC 312 wireless L	CIC 312 (wireless) Sensorik	13.20.22.7655	2*
Genesis AI 12 CIC 312 wireless M	CIC 312 (wireless) Sensorik	13.20.22.7656	2*
Genesis AI 12 CIC 312 wireless P	CIC 312 (wireless) Sensorik	13.20.22.7657	2*
Genesis AI 12 CIC 312 wireless UP	CIC 312 (wireless) Sensorik	13.20.22.7658	2*

Genesis AI CIC nw

Genesis AI 24 CIC 10 NW nw L	CIC 10 NW (non-wireless)	13.20.22.7249	3*
Genesis AI 24 CIC 10 NW nw M	CIC 10 NW (non-wireless)	13.20.22.7245	3*
Genesis AI 24 CIC 10 NW nw P	CIC 10 NW (non-wireless)	13.20.22.7254	3*
Genesis AI 24 CIC 10 NW nw UP	CIC 10 NW (non-wireless)	13.20.22.7251	3*
Genesis AI 24 CIC 312 NW nw L	CIC 312 NW (non-wireless)	13.20.22.7257	3*
Genesis AI 24 CIC 312 NW nw M	CIC 312 NW (non-wireless)	13.20.22.7246	3*
Genesis AI 24 CIC 312 NW nw P	CIC 312 NW (non-wireless)	13.20.22.7253	3*
Genesis AI 24 CIC 312 NW nw UP	CIC 312 NW (non-wireless)	13.20.22.7259	3*
Genesis AI 20 CIC 10 NW nw L	CIC 10 NW (non-wireless)	13.20.22.7244	3*
Genesis AI 20 CIC 10 NW nw M	CIC 10 NW (non-wireless)	13.20.22.7260	3*
Genesis AI 20 CIC 10 NW nw P	CIC 10 NW (non-wireless)	13.20.22.7247	3*
Genesis AI 20 CIC 10 NW nw UP	CIC 10 NW (non-wireless)	13.20.22.7255	3*
Genesis AI 20 CIC 312 NW nw L	CIC 312 NW (non-wireless)	13.20.22.7256	3*
Genesis AI 20 CIC 312 NW nw M	CIC 312 NW (non-wireless)	13.20.22.7261	3*
Genesis AI 20 CIC 312 NW nw P	CIC 312 NW (non-wireless)	13.20.22.7248	3*
Genesis AI 20 CIC 312 NW nw UP	CIC 312 NW (non-wireless)	13.20.22.7252	3*
Genesis AI 16 CIC 10 NW nw L	CIC 10 NW (non-wireless) Batterie 312	13.20.22.7235	3*
Genesis AI 16 CIC 10 NW nw M	CIC 10 NW (non-wireless) Batterie 312	13.20.22.7226	3*
Genesis AI 16 CIC 10 NW nw P	CIC 10 NW (non-wireless) Batterie 312	13.20.22.7233	3*
Genesis AI 16 CIC 10 NW nw UP	CIC 10 NW (non-wireless) Batterie 312	13.20.22.7232	3*
Genesis AI 16 CIC 312 NW nw L	CIC 312 NW (non-wireless) Batterie 312	13.20.22.7228	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Genesis AI 16 CIC 312 NW nw M	CIC 312 NW (non-wireless) Batterie 312	13.20.22.7231	3*
Genesis AI 16 CIC 312 NW nw P	CIC 312 NW (non-wireless) Batterie 312	13.20.22.7229	3*
Genesis AI 16 CIC 312 NW nw UP	CIC 312 NW (non-wireless) Batterie 312	13.20.22.7234	3*
Genesis AI 12 CIC 10 NW nw L	CIC 10 NW (non-wireless) Batterie 10	13.20.22.7734	2*
Genesis AI 12 CIC 10 NW nw M	CIC 10 NW (non-wireless) Batterie 10	13.20.22.7735	2*
Genesis AI 12 CIC 10 NW nw P	CIC 10 NW (non-wireless) Batterie 10	13.20.22.7736	2*
Genesis AI 12 CIC 10 NW nw UP	CIC 10 NW (non-wireless) Batterie 10	13.20.22.7737	2*
Genesis AI 12 CIC 312 NW nw L	CIC 312 NW (non-wireless) Batterie 10	13.20.22.7738	2*
Genesis AI 12 CIC 312 NW nw M	CIC 312 NW (non-wireless) Batterie 10	13.20.22.7739	2*
Genesis AI 12 CIC 312 NW nw P	CIC 312 NW (non-wireless) Batterie 10	13.20.22.7740	2*
Genesis AI 12 CIC 312 NW nw UP	CIC 312 NW (non-wireless) Batterie 10	13.20.22.7741	2*
Genesis AI IIC nw			
Genesis AI 24 IIC 10 nw L	IIC (non-wireless) Batterie 10	13.20.22.7250	3*
Genesis AI 24 IIC 10 nw M	IIC (non-wireless) Batterie 10	13.20.22.7283	3*
Genesis AI 20 IIC 10 nw L	IIC (non-wireless) Batterie 10	13.20.22.7243	3*
Genesis AI 20 IIC 10 nw M	IIC (non-wireless) Batterie 10	13.20.22.7258	3*
Genesis AI 16 IIC 10 nw L	IIC (non-wireless) Batterie 10	13.20.22.7227	3*
Genesis AI 16 IIC 10 nw M	IIC (non-wireless) Batterie 10	13.20.22.7230	3*
Starkey Signature Series			
Starkey Signature Series 24 CIC R NW			
Starkey Signature Series 24 CIC R NW L	CIC R NW (non-wireless) Akku	13.20.23.8439	3*
Starkey Signature Series 24 CIC R NW M	CIC R NW (non-wireless) Akku	13.20.23.8440	3*
Starkey Signature Series 24 CIC R NW P	CIC R NW (non-wireless) Akku	13.20.23.8441	3*
Starkey Signature Series 24 CIC R NWUP	CIC R NW (non-wireless) Akku	13.20.23.8438	3*
Starkey Signature Series 20 CIC R NW L	CIC R NW (non-wireless) Akku	13.20.23.8675	3*
Starkey Signature Series 20 CIC R NW M	CIC R NW (non-wireless) Akku	13.20.23.8676	3*
Starkey Signature Series 20 CIC R NW P	CIC R NW (non-wireless) Akku	13.20.23.8677	3*
Starkey Signature Series 20 CIC R NWUP	CIC R NW (non-wireless) Akku	13.20.23.8678	3*
Starkey Signature Series 16 CIC R NW L	CIC R NW (non-wireless) Akku	13.20.23.8671	3*
Starkey Signature Series 16 CIC R NW M	CIC R NW (non-wireless) Akku	13.20.23.8672	3*
Starkey Signature Series 16 CIC R NW P	CIC R NW (non-wireless) Akku	13.20.23.8673	3*
Starkey Signature Series 16 CIC R NWUP	CIC R NW (non-wireless) Akku	13.20.23.8674	3*
Starkey Signature Series 24 CIC NW 10			
Starkey Signature Series 24 CIC NW 10 L	CIC NW (non-wireless) Batterie 10	13.20.22.7535	3*
Starkey Signature Series 24 CIC NW 10 M	CIC NW (non-wireless) Batterie 10	13.20.22.7536	3*
Starkey Signature Series 24 CIC NW 10 P	CIC NW (non-wireless) Batterie 10	13.20.22.7534	3*
Starkey Signature Series 24 CIC NW 10 UP	CIC NW (non-wireless) Batterie 10	13.20.22.7537	3*
Starkey Signature Series 20 CIC NW 10 L	CIC NW (non-wireless) Batterie 10	13.20.22.7724	3*
Starkey Signature Series 20 CIC NW 10 M	CIC NW (non-wireless) Batterie 10	13.20.22.7725	3*
Starkey Signature Series 20 CIC NW 10 P	CIC NW (non-wireless) Batterie 10	13.20.22.7726	3*
Starkey Signature Series 20 CIC NW 10 UP	CIC NW (non-wireless) Batterie 10	13.20.22.7727	3*
Starkey Signature Series 16 CIC NW 10 L	CIC NW (non-wireless) Batterie 10	13.20.22.7716	3*
Starkey Signature Series 16 CIC NW 10 M	CIC NW (non-wireless) Batterie 10	13.20.22.7717	3*
Starkey Signature Series 16 CIC NW 10 P	CIC NW (non-wireless) Batterie 10	13.20.22.7718	3*
Starkey Signature Series 16 CIC NW 10 UP	CIC NW (non-wireless) Batterie 10	13.20.22.7719	3*
Starkey Signature Series 24 CIC NW 312			
Starkey Signature Series 24 CIC NW 312 L	CIC NW (non-wireless) Batterie 312	13.20.22.7526	3*
Starkey Signature Series 24 CIC NW 312 M	CIC NW (non-wireless) Batterie 312	13.20.22.7529	3*
Starkey Signature Series 24 CIC NW 312 P	CIC NW (non-wireless) Batterie 312	13.20.22.7528	3*

Hörsystem	Bauform	HMV-Nummer	BG-Nummer*
Starkey Signature Series 24 CIC NW 312 UP	CIC NW (non-wireless) Batterie 312	13.20.22.7527	3*
Starkey Signature Series 20 CIC NW 312 L	CIC NW (non-wireless) Batterie 312	13.20.22.7728	3*
Starkey Signature Series 20 CIC NW 312 M	CIC NW (non-wireless) Batterie 312	13.20.22.7729	3*
Starkey Signature Series 20 CIC NW 312 P	CIC NW (non-wireless) Batterie 312	13.20.22.7730	3*
Starkey Signature Series 20 CIC NW 312 UP	CIC NW (non-wireless) Batterie 312	13.20.22.7731	3*
Starkey Signature Series 16 CIC NW 312 L	CIC NW (non-wireless) Batterie 312	13.20.22.7720	3*
Starkey Signature Series 16 CIC NW 312 M	CIC NW (non-wireless) Batterie 312	13.20.22.7721	3*
Starkey Signature Series 16 CIC NW 312 P	CIC NW (non-wireless) Batterie 312	13.20.22.7722	3*
Starkey Signature Series 16 CIC NW 312 UP	CIC NW (non-wireless) Batterie 312	13.20.22.7723	3*

Starkey Signature Series 24 IIC NW

Starkey Signature Series 24 IIC NW L	IIC NW (non-wireless) Batterie	13.20.22.7501	3*
Starkey Signature Series 24 IIC NW M	IIC NW (non-wireless) Batterie	13.20.22.7502	3*

CROS | BiCROS - Universelle Nummern

CROS		13.99.01.5000	3*
BiCROS		13.99.01.6000	3*

*Bitte beachten Sie, dass die BG-Einteilung lediglich eine Empfehlung von Starkey ist. Diese sollten individuell mit den Versorgungspauschalen überprüft werden.

Evolv AI

Evolv AI HdO R | HdO 13 | HdO P+

Evolv AI 2400 HdO R	HdO R (Li-Ion Akku) Sensorik Taster	13.20.23.9300	3*
Evolv AI 2000 HdO R	HdO R (Li-Ion Akku) Sensorik Taster	13.20.23.9081	3*
Evolv AI 1600 HdO R	HdO R (Li-Ion Akku) Sensorik Taster	13.20.23.9084	3*
Evolv AI 1200 HdO R	HdO R (Li-Ion Akku) Sensorik Taster	13.20.23.9082	3*
Evolv AI 1000 HdO R	HdO R (Li-Ion Akku) Sensorik Taster	13.20.23.9083	3*
Evolv AI 2400 HdO R (Tinnitus)	HdO R (Li-Ion Akku) Sensorik Taster	13.20.14.8783	3*
Evolv AI 2000 HdO R (Tinnitus)	HdO R (Li-Ion Akku) Sensorik Taster	13.20.14.8993	3*
Evolv AI 1600 HdO R (Tinnitus)	HdO R (Li-Ion Akku) Sensorik Taster	13.20.14.8781	3*
Evolv AI 1200 HdO R (Tinnitus)	HdO R (Li-Ion Akku) Sensorik Taster	13.20.14.8780	2*
Evolv AI 1000 HdO R (Tinnitus)	HdO R (Li-Ion Akku) Sensorik Taster	13.20.14.8782	2*

CROS | BiCROS - Universelle Nummern

CROS		13.99.01.5000	
BiCROS		13.99.01.6000	

*Bitte beachten Sie, dass die BG-Einteilung lediglich eine Empfehlung von Starkey ist. Diese sollten individuell mit den Versorgungspauschalen überprüft werden.

MISC_16_DE_ST_Hilfsmittelpositionsnummern_April2026