


## Axon Aware Mobile App Overview

After you sign in to the Axon Aware Mobile App, the map is shown. The app uses standard smart device actions to move around the map, zoom in, and zoom out.



### Axon Aware Mobile App Controls

	App Settings and Sign Out
	User screen/tab: View list of officers and search for officers
	Map screen/tab: View map
	Center map on your location
	Alerts: Tap for more information <ul style="list-style-type: none"> <li>• gray = no alerts,</li> <li>• red = active alerts</li> </ul>
	Opens user list to search for officers
	Filter: Hide non-recording cameras without alerts and toggle between satellite and normal map view.

### Axon Aware Mobile App Map Icons


	Camera marker: camera recording,
	Camera marker: camera not recording
	Multiple cameras, indicated by number, at location. Tap or manually zoom in to see individual camera markers.

# Axon Aware Mobile App Quick Reference Sheet (cont.)

## Viewing a Livestream

On the Aware Map or search, find the officer you want to livestream and tap the associated camera icon. You can only livestream cameras that are recording (showing green status).

Tap the Play icon to start the livestream. Tap the close (X) icon to end the livestream.




Tap the full screen icon to view the livestream in full screen mode.



## Axon Aware Mobile App PIN Code

Due to the potentially sensitive information presented in Axon Aware, the Axon Aware mobile app requires the use of a PIN code when opening the app.

Additionally, if you are inactive or away from the app for more than 30 minutes, you are asked to enter your PIN code when opening the app.



- When you sign in to the Axon Aware mobile app for the first time, you are asked to set up a 6-digit PIN code.
- If you forget your PIN, tap **Reset PIN code** and you are signed out of the app. When you sign in to the mobile app again, you are asked to set up a new PIN.

### You will be logged out

You will need to re-login with Evidence.com credentials to reset PIN code.

OK Cancel

If you enter the incorrect PIN code 5 times, you are automatically signed out. To continue using the app, you must sign in and set up a new PIN code.