

TASER 7

ENERGY WEAPON QUICK START GUIDE




1. COMPLETE TRAINING FIRST.

2. CONFIRM THE ENERGY WEAPON IS READY FOR USE

Check with your armorer to be sure the batteries have gone through a full dock cycle (with a green LED), the firmware is up to date, the energy weapon has the correct setup for your agency, and that the weapon, cartridges, and battery packs have been properly assigned to you.


3. INSERT THE BATTERY

- A) Insert the battery pack into the weapon. Press firmly until you hear both latches “click.”
- B) Inserting a new battery pack will synchronize the weapon's logs to the battery pack and may update the energy weapon firmware automatically. Do not remove the battery pack from the energy weapon until the hourglass icon disappears from the CID.




4. TURN THE ENERGY WEAPON ON AND OFF


- A) Point the energy weapon in a safe direction.
- B) Shift the safety switch to the up **(ARMED)** position.



If the battery pack is fully charged, the Critical Information Display (CID) should look like this:




- C) Shift the safety switch to the down **(SAFE)** position.



5. WORKING WITH CARTRIDGES

Point the energy weapon in a safe direction. Be sure the safety is in the down **(SAFE)** position. Do not put your hands in front of the cartridges. Remove the cartridges from the safety clip.



CARTRIDGE COLOR CODE



BLACK = Live Cartridge, Standoff (3.5°) or Close-quarter (12°).
For field use.



BLUE = Hook and Loop Training (HALT) Cartridge, Standoff (3.5°) or Close-quarter (12°).
For training use only.
DO NOT USE IN FIELD.




RED = Inert Training Cartridge (no probes).
For training use only.
DO NOT USE IN FIELD.



WHITE = Virtual Reality (VR) Cartridge (no probes).
For training use only.
DO NOT USE IN FIELD.


6. DISASSEMBLE/REASSEMBLE THE CARTRIDGES

A) To disassemble, pull the cartridges apart from each other.



B) To assemble, first align the attachment tabs.

C) Press the cartridges together.




7. LOAD THE CARTRIDGES

Never place your hands, fingers, or other body parts in front of the cartridge. This is especially important when loading and unloading the cartridge, as serious injury could result. When loading and unloading always hold the cartridge on the sides.

Be sure to load the cartridges right side up. The top of the cartridge has text on it.

A) Push the cartridges into the cartridge bay until you hear a “click.”

B) Then give the cartridges a slight tug to ensure they are locked into place.



8. CONFIRM THE ENERGY WEAPON RECOGNIZES THE CARTRIDGES

After loading the energy weapon:

A) Point the energy weapon in a safe direction.

B) Shift the safety switch to the up (ARMED) position.

C) Confirm the CID displays both cartridges.

D) Shift the safety to the down (SAFE) position.




9. UNLOAD THE CARTRIDGES

Point the energy weapon in a safe direction. Be sure the safety is in the down (SAFE) position. Do not put your hands in front of the cartridges.

A) Press the cartridge release button on top of the energy weapon.

B) Pull the cartridges up and out of the energy weapon.



10. RECHARGE THE BATTERY

A) Shift the safety switch to the down (SAFE) position.

B) Confirm the CID is blank.

C) Press the 2 buttons on each side of the battery pack.

D) Pull the battery pack out of the energy weapon.

E) Press the battery pack into the dock. You should hear a click when the battery pack is seated properly in the bay.

After the battery is fully recharged and all information is uploaded to Axon Evidence (Evidence.com) services, the light on the dock next to the battery pack will be solid green.

