

MASONRY WALL BLANKET

INSTALL INSTRUCTIONS

The total R-Value of the building system depends on the building materials, design and installation and may be less than, greater than or equal to the R-Value of this product. GreenStuf® polyester insulation products have an indefinite life and carry a 50 Year Product Durability Warranty.

The initial performance of this product may be reduced if it is stored for too long in its compressed packaging. Should this product be found to be compressed at installation, it will recover to its nominal thickness and R-Value within 72 Hours following installation. Greenstuf should be removed from compressed packaging within 6 months of manufacturing. GreenStuf will not settle or reduce its performance over time and if installed in accordance with these manufacturer's instructions, it will meet and exceed the 50 year durability clause of the NZBC (B2.3.1(a)).

CAUTION: Electric cables and equipment partially or completely surrounded with any bulk thermal insulation may overheat and fail. This applies to wiring installed prior to 1989. Please follow the installation instructions.

TECHNICAL

We recommend all thermal insulation is installed in accordance with NZS 4246:2016 Energy Efficiency – Installing Insulation in Residential Buildings. Copies of this Standard are available from Standards New Zealand.

GreenStuf is completely safe to handle and no protective clothing, gloves or masks are required for handling or installing this product.

Cutting to size: always cut GreenStuf slightly oversized to ensure a tight friction fit. GreenStuf Masonry Wall Blanket can be cut using an insulation knife or mechanical fabric cutters.

Friction fit the GreenStuf Masonry Wall Blanket between the strapping to completely fill the whole space between. Slightly oversize length for friction fit and cut across the width of the roll. Cut smaller pieces for smaller spaces and around penetrations. Leave no gaps and maintain full thickness over the whole of the installation.

Insulation should be stapled to the strapping/battens each side at the top of each drop to hold the insulation in place until the wall linings are in place.

Install the blanket as a continuous roll between the strapping/battens. The blanket ideally should have no joins inside the framed cavity. Where joins are necessary, ensure a tight fit with no gaps or folds and fix securely in place by stapling edges to the strapping.

GreenStuf Masonry Wall Blanket is manufactured from 100% polyester fibres and will not wick moisture. As such, GreenStuf can be installed directly against concrete/masonry walls.

Timber strapping/battens should be isolated from concrete/masonry with DPC.

GGreenStuf polyester is considered non-corrosive based on AS/NZS 4859.1 standard for insulation.



GreenStuf® FACTORY AND COLLECTIONS

40 Westpoint Drive,
Hobsonville, Auckland 0618,
New Zealand

FREEPHONE **0800 428 839**

PHONE **+64 9 828 9179**

FAX **+64 9 828 5810**

WEB **greenstuf.co.nz**

AN ISO 9001, ISO 14001 AND ISO 45001 CERTIFIED COMPANY

The brand names and logos mentioned herein are registered or unregistered trademarks either owned or used under license by Autex Industries Limited or other members of the Autex Group. The contents of this document are protected by Copyright 2026 Autex Industries Ltd. All Rights Reserved.

It is the user's responsibility to determine if the product and information presented in this document are suitable for the intended application by engaging a suitably qualified consultant. The information contained in this document is correct to the best of our knowledge at the date of its publication. To verify that this document is the most current publication please check our website or contact your GreenStuf® account manager.